


# MODEL 42591x86A

## REPAIR PARTS CHASSIS & HOOD




# MODEL 42591x86A

# REPAIR PARTS CHASSIS & HOOD

| Key No. | Description    | Part No.  | Key No. | Description           | Part No.  |
|---------|----------------|-----------|---------|-----------------------|-----------|
| 1       | Seat           | 94162     | 30      | Bezel, Right          | 94088 Z   |
| 2       | Cap, Push On   | 28x23     | 31      | Screw                 | 26x270    |
| 3       | Spring         | 94057     | 32      | Screw                 | 26x238    |
| 4       | Screw          | 26x229    | 33      | Bearing, Steering     | 94075     |
| 5       | Bolt, Wing     | 94160     | 34      | Dash                  | 94590E700 |
| 6       | Washer         | 17x47 Z   | 35      | Nut                   | 15x84     |
| 7       | Bolt, Shoulder | 9x56      | 36      | Panel, Access         | 93007E700 |
| 8       | Support, Seat  | 94154E700 | 37      | Support, Dash         | 95318E700 |
| 9       | Rod, Pivot     | 94156 Z   | 38      | Bracket, Rear Hanger  | 94013E700 |
| 10      | Bracket, Pivot | 94153E700 | 39      | Support, Left Grille  | 94085E700 |
| 11      | Bolt           | 1x45      | 40      | Axle, Hanger          | 94007E700 |
| 12      | Nut            | 15x89     | 41      | Support, Right Grille | 94084E700 |
| 13      | Bolt, Shoulder | 9x55      | 42      | Bolt, Shoulder        | 9x58      |
| 14      | Washer         | 94155 Z   | 43      | Frame, Right          | 94000E700 |
| 15      | Spring         | 164x31    | 44      | Frame, Left           | 94001E700 |
| 16      | Screw          | 26x249    | 45      | Container, Battery    | 94069     |
| 17      | Screw          | 26x263    | 46      | Plate, Hitch          | 94002E700 |
| 18      | Spring         | 164x30    | 47      | Panel, Rear           | 94187E700 |
| 19      | Deck, Seat     | 94150E245 | 49      | Panel, Left Side      | 95218E700 |
| 20      | Nut            | 15x88     | 50      | Panel, Right Side     | 95217E700 |
| 21      | Plate, Index   | 94886E700 | 55      | Plate, Rear           | 94186E700 |
| 23      | Mat, Left      | 94453     | 58      | Extension, Spring     | 165x124   |
| 24      | Mat, Right     | 94454     | 59      | Bracket               | 94830 Z   |
| 25      | Hood           | 94090E245 | 61      | Screw                 | 26x201    |
| 26      | Grille         | 94087E700 | —       | Decal, Right Hood     | 44x7984   |
| 27      | Lens, Left     | 94093     | —       | Decal, Left Hood      | 44x7983   |
| 28      | Bezel, Left    | 94089 Z   | —       | Decal, Warning        | 44x6815   |
| 29      | Lens, Right    | 94092     | —       | Book, Instruction     | F-98921   |

# MODEL 42591x86A

## REPAIR PARTS MOTION DRIVE




# MODEL 42591x86A

# REPAIR PARTS MOTION DRIVE

| Key No. | Description             | Part No.  | Key No. | Description              | Part No.  |
|---------|-------------------------|-----------|---------|--------------------------|-----------|
| 1       | Screw                   | 26x249    | 33      | Rod, Yoke                | 94425E700 |
| 2       | Nut, Flange             | 15x84     | 34      | Spring, Extension        | 165x92    |
| 3       | Guide, Belt             | 93349     | 35      | Washer                   | 17x169    |
| 4       | Bracket, Idler          | 94431E700 | 36      | Bracket, Pivot           | 94035E700 |
| 5       | Locknut                 | 15x79     | 37      | Lever, Clutch/Brake      | 94038E700 |
| 6       | Washer                  | 17x47 Z   | 38      | Strap, Left Torque       | 94433E700 |
| 7       | Rod, Clutch             | 94417 Z   | 39      | Rod, Pedal Link          | 94424 Z   |
| 8       | Pin, Cotter             | 30x20     | 40      | Grip                     | 91079     |
| 9       | Adjuster                | 94815     | 41      | Pedal, Speed Control     | 94422E700 |
| 10      | Latch, Parking Brake    | 94045 Z   | 42      | Washer                   | 17x148    |
| 11      | Bracket Assembly, Idler | 94411 Z   | 43      | Arm, Disconnect          | 94430 Z   |
| 12      | Bolt, Shoulder          | 9x39      | 44      | Spring                   | 165x112   |
| 13      | Rod, Parking Brake      | 95005 Z   | 45      | Bolt                     | 1x145     |
| 14      | Bracket, Left Transaxle | 94185E700 | 46      | Lockwasher               | 18x32     |
| 15      | Belt                    | 37x61     | 47      | Washer                   | 17x180    |
| 16      | Pulley, Idler           | 91179     | 48      | Washer                   | 17x91     |
| 17      | Arm Assembly, Idler     | 94409 Z   | 49      | Transaxle **             | **        |
| 18      | Pulley, Idler           | 91178     | 50      | Key, Square              | 21553     |
| 19      | Pedal                   | 21544     | 51      | Bracket, Right Transaxle | 94184E700 |
| 20      | Frame, Left             | 94001E700 | 52      | Bolt                     | 1x155     |
| 21      | Frame, Right            | 94000E700 | 53      | Spring, Extension        | 165x92    |
| 22      | Nut, Flange             | 15x88     | 54      | Clamp, Transaxle         | 94434E700 |
| 23      | Spring, Extension       | 165x123   | 55      | Washer                   | 17x160    |
| 24      | Rod, Disconnect         | 94428 Z   | 56      | Spacer                   | 87x105 Z  |
| 25      | Bracket, Disconnect     | 94429E700 | 57      | Washer                   | 17x195    |
| 26      | Bolt, Carriage          | 2x53      | 58      | E-Ring                   | 11x3      |
| 27      | Screw                   | 26x216    | 59      | Valve Stem               | 24373     |
| 28      | Strap, Right Torque     | 94432E700 | 60      | Wheel & Tire Assembly    | 92290-601 |
| 29      | Rod, Link               | 94426 Z   | 61      | Tire *                   | 92374     |
| 30      | Pin, Hair               | 31x4      | —       | Tube                     | 407049    |
| 31      | Pin, Hair               | 31x6      | 62      | Cap, Hub                 | 94618     |
| 32      | Nut, Adjuster           | 92132     | 63      | Guide, Belt              | 94781     |

\* When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.

\*\* For information on Replacement Parts see the Central Parts Distributor in your area.




# MODEL 42591x86A

# REPAIR PARTS STEERING

| Key No. | Description            | Part No.  | Key No. | Description             | Part No.  |
|---------|------------------------|-----------|---------|-------------------------|-----------|
| 1       | Wheel, Steering        | 95336     | 23      | Washer                  | 17x104    |
| 2       | Post, Steering         | 94520     | 24      | Washer                  | 17x53 Z   |
| 3       | Insert, Steering Wheel | 95338     | 25      | Nut, Flange             | 15x84     |
| 4       | Bearing                | 94124     | 26      | Axle Assembly           | 94012E700 |
| 5       | Nut, Flange            | 15x113    | 27      | Drag Link, Left         | 94021E700 |
| 6       | Bolt, Shoulder         | 9x57      | 28      | Spindle Assembly, Right | 94575E700 |
| 7       | Gear, Pinion           | 94122E700 | 29      | Drag Link, Right        | 94020E700 |
| 8       | Ring, Snap             | 11x25     | 30      | Screw                   | 26x249    |
| 9       | Gear, Sector           | 94121E700 | 31      | Bearing, Wheel          | 91334     |
| 10      | Bearing                | 94123     | 32      | Stem, Valve             | 24373     |
| 11      | Bolt                   | 1x84      | 33      | Tire *                  | 91912     |
| 12      | Plate, Steering        | 94003E700 | —       | Tube                    | 407924    |
| 13      | Plate, Engine          | 94006E700 | 34      | Wheel and Tire Assembly | 94579–601 |
| 14      | Nut, Flange            | 15x88     | 35      | Washer                  | 17x195    |
| 15      | Nut, Flange            | 15x118    | 36      | Washer                  | 17x192    |
| 16      | Bracket, Hanger        | 94013E700 | 37      | Washer                  | 17x113    |
| 17      | Axle, Hanger           | 94007E700 | 38      | Hub Cap                 | 94618     |
| 18      | Bolt                   | 1x146     | 39      | Screw                   | 26x267    |
| 19      | Pin, Cotter            | 30x49     | 40      | Bellows                 | 54789     |
| 20      | Bearing                | 92527     | 41      | Bolt                    | 1x158     |
| 21      | Spindle Assembly, Left | 94576E700 | 42      | Lockwasher              | 18x32     |
| 22      | Bolt                   | 1x111     | 43      | Washer                  | 17x146 Z  |

\* When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.




# MODEL 42591x86A

# REPAIR PARTS MOWER HOUSING SUSPENSION

| Key No. | Description     | Part No.  | Key No. | Description              | Part No.  |
|---------|-----------------|-----------|---------|--------------------------|-----------|
| 1       | Grip            | 92698     | 23      | Screw                    | 26x49     |
| 2       | Handle, PTO     | 94100 Z   | 24      | Pin, Hair                | 31x4      |
| 3       | Pad, Switch     | 94022 Z   | 25      | Washer                   | 17x91 Z   |
| 4       | Bolt            | 25x3      | 26      | Link, Right Lift         | 94053E700 |
| 5       | Grip            | 92697     | 27      | Lever Assembly, Lift     | 94180E700 |
| 6       | Spring          | 166x40    | 28      | Nut, Flange              | 15x118    |
| 7       | Washer          | 17x103    | 29      | Plate, Lift Arm          | 94030E700 |
| 8       | Handle, Lift    | 94195 Z   | 30      | Pin                      | 94067     |
| 9       | Lever, PTO      | 94017 Z   | 31      | Bracket, Rear Suspension | 94055E700 |
| 10      | Bolt, Shoulder  | 9x39      | 32      | Bushing                  | 94065     |
| 11      | Pin, Cotter     | 30x20     | 33      | Bolt, Shoulder           | 9x53      |
| 12      | Washer          | 17x57     | 34      | Bracket, Pivot           | 94015E700 |
| 13      | Link, PTO       | 94004 Z   | 35      | Tube, Deck Lift          | 94063E700 |
| 14      | Nut, Flange     | 15x84     | 36      | Washer                   | 17x191    |
| 15      | Screw           | 26x249    | 37      | Nut, Flange              | 15x84     |
| 16      | Spring          | 166x39    | 38      | Spring                   | 165x117   |
| 17      | Bracket, PTO    | 94018E700 | 39      | Nut, Flange              | 15x68     |
| 18      | Spring          | 165x119   | 40      | Bracket, PTO             | 94005E700 |
| 19      | Crank, PTO      | 94019E700 | 41      | Hanger, Left Deck        | 94027E700 |
| 20      | Link, Left Lift | 94611E700 | 42      | Hanger, Right Deck       | 94026E700 |
| 21      | Link, Lift      | 94028 Z   | 43      | Rod, Hanger              | 94158 Z   |
| 22      | Bolt            | 1x74      | 44      | Bracket, Suspension      | 94058E700 |

# MODEL 42591x86A

# REPAIR PARTS MOWER HOUSING




# MODEL 42591x86A


# REPAIR PARTS MOWER HOUSING

| Key No. | Description               | Part No.  | Key No. | Description                     | Part No.  |
|---------|---------------------------|-----------|---------|---------------------------------|-----------|
| 1       | Pulley, Jackshaft         | 94199     | 31      | Plate                           | 92426E700 |
| 2       | Nut, Hex                  | 15x121    | 32      | Nut, Flange                     | 15x88     |
| 3       | Belt, Mower Drive         | 37x88     | 33      | Bolt, Carriage                  | 2x53      |
| 4       | Pulley, Idler             | 91801     | 34      | Mandrell Housing                | 92574     |
| 5       | Nut, Flange               | 15x84     | 35      | Bracket, Suspension             | 94058E700 |
| 6       | Jackshaft                 | 94129     | 36      | Adapter, Blade                  | 94199     |
| 7       | Spacer                    | 94130     | 37      | Blade                           | 95102E701 |
| 8       | Link, Left Lift           | 94053E700 | 38      | Washer                          | 17x166    |
| 9       | Pad, Friction             | 94137     | 39      | Washer                          | 17x165    |
| 10      | Bolt, Shoulder            | 9x52      | 40      | Nut                             | 15x100    |
| 11      | Bracket, Suspension       | 94055E700 | 41      | Spring                          | 166x4     |
| 12      | Pad Assembly, Left Brake  | 94049E700 | 42      | Cap, Push On                    | 28x23     |
| 13      | Knob                      | 94068     | 43      | Rod, Deflector                  | 94957 Z   |
| 14      | Bolt, Shoulder            | 9x51      | 44      | Deflector Assembly              | 94707 SE  |
| 15      | Plate, Suspension         | 94128E700 | 45      | Bracket, Deflector Hinge        | 94956E700 |
| 16      | Spring                    | 166x43    | 46      | Bracket, Front Hanger           | 94686E700 |
| 17      | Nut, Flange               | 15x79     | 47      | Washer                          | 17x45 Z   |
| 18      | Bracket, Suspension       | 94192E700 | 48      | Guide, Belt                     | 94781     |
| 19      | Pin, Hanger               | 94064     | 49      | Link, Right Lift                | 94611E700 |
| 20      | Washer                    | 17x103    | 50      | Bolt, Axle                      | 94025     |
| 21      | Pin, Hair                 | 31x4      | 51      | Washer                          | 17x91 Z   |
| 22      | Bolt                      | 25x7      | 52      | Spring, Extension               | 165x119   |
| 23      | Cover, Pulley             | 94051E700 | 53      | Wheel, Gage                     | 92683     |
| 24      | Bolt, Shoulder            | 9x39      | 54      | Bracket, Right Wheel            | 92422E700 |
| 25      | Arm, Idler                | 94177E700 | 55      | Bracket, Left Wheel             | 92423E700 |
| 26      | Spring                    | 166x41    | 57      | Screw                           | 26x249    |
| 27      | Pad Assembly, Right Brake | 94047E700 | 58      | Stiffener                       | 94604E700 |
| 28      | Bracket, Brake            | 94193E700 | 59      | Housing, Blade *                | 94814E700 |
| 29      | Spring                    | 166x42    | 60      | Ring, Locking                   | 31x11     |
| 30      | Bracket, Suspension       | 94191E700 | 1-60    | Complete Mower Housing Assembly | 776007    |

\* Includes Key No. 17, 18, 30, 31, 32, 33, 45, 46, 53, 54, 55, and 56.



| Key No. | Description           | Part No.  |
|---------|-----------------------|-----------|
| 1       | Fuel Cap              | 92317     |
| 2       | Fuel Tank             | 94073     |
| 3       | Hose Clamp            | 95197     |
| 4       | Fuel Line             | 90671     |
| 5       | Hose Clamp            | 95197     |
| 6       | Screw                 | 26x201    |
| 7       | Plate, Engine         | 94006E700 |
| 8       | Throttle Control      | 91989     |
| 9       | Engine                | _____     |
| 10      | Bolt, Engine Mount    | 25x7      |
| 11      | Stack Pulley Assembly | 94407 Z   |
| 12      | Lockwasher            | 19x35     |
| 13      | Bolt, Hex             | 1x140     |
| 14      | Washer                | 17x170    |
| 15      | Screw                 | 26x249    |
| 21      | Guide, Belt           | 93349     |
| 22      | Nut, Flange           | 15x79Z    |
| 23      | Guide, Belt           | 94066     |
| 26      | Screw                 | 26x253    |
| 27      | Spacer                | 93077     |
| 28      | Pipe, Exhaust         | 92855     |
| 29      | Clamp                 | 92558     |
| 30      | Shield, Heat          | 94324     |
| 31      | Screw                 | 26x263    |



| Key No. | Description               | Part No. |
|---------|---------------------------|----------|
| 1       | Harness, Light Wire       | 250x68   |
|         | Socket, Light             | 92372    |
|         | Bulb, Light               | 90084    |
| 2       | Harness, Chassis Wire     | 250x87   |
| 3       | Switch, Ignition          | 92556    |
|         | Key, Ignition             | 20729    |
|         | Nut, Hex                  | 91489    |
|         | Cap, Ignition             | 91488    |
| 4       | Switch, Limit             | 94136    |
| 5       | Fuse                      | 54212    |
|         | Holder, Fuse              | 407078   |
| 6       | Solenoid                  | 94613    |
|         | Screw, Mounting           | 26x229   |
|         | Locknut                   | 15x116   |
| 7       | Cable, Battery Ground     | 24x32    |
|         | Screw, Ground Cable       | 26x213   |
| 8       | Battery                   | 21075    |
|         | Bolt, Carriage            | 2x82     |
|         | Wingnut                   | 14x79    |
| 9       | Harness, Seat Switch Wire | 250x67   |
| 10      | Switch, Seat Sensor       | 94159    |
| 11      | Cable                     | 24x31    |