


# MODEL 24050x20C

# REPAIR PARTS GRASS BAGGER



# MODEL 24050x20C

# REPAIR PARTS GRASS BAGGER

Key No.	Description	Part No.
1	Window	54575
2	Cover	54577
3	Screw	4x24
4	Locknut	15x66
5	Tube, "U"	54410E701
6	Pin, Hair	31x6
7	Pin, Hinge	54407Z
8	Tube, Center	54412E701
9	Bolt, Special	6x93Z
10	Lockwasher	18x15
11	Nut, Hex	15x32
12	Channel Assembly	54422E701
13	Pin, Channel	54408Z
14	Bolt, Hex	1x91
15	Hitch Assembly	54499E701
17	Cap, End	24862
18	Elbow	54415
20	Handle, Connector Tube	54416E701
21	Locknut, Flange	15x89
22	Latch, Rubber	54695
23	Wingnut	14x86
24	Tube, Chute Extension	54554
25	Locknut	15x76
26	Pin, Latch	54563
27	Bolt, Carriage	2x39
29	Tube, Connector	54555
30	Screw	4x71
31	Hinge, Cover	54398E701
36	Fastener, Plastic *	193x1
37	Containers (Quantity 2)	54727SE
41	Bolt, Carriage	2x64
42	Shell, Front Weight	55442
43	Plug, Front Weight	24863
45	Bracket, Front Weight	54551E701
47	Bracket, Support	54562E701
48	Screw	26x239
51	Handle, Plastic	54537
52	Screw	4x21
53	Nut, Hex	15x81
54	Blade, High-Lift	56246E701
-	Instruction Book	F-96900

\* Included with Key No. 37.